

---

# AUTOMATIC TRANSMISSION

## CONTENTS

120002617

<b>GENERAL INFORMATION</b> .....	<b>2</b>	Inhibitor Switch and Control Cable Adjustment .....	12
<b>SERVICE SPECIFICATIONS</b> .....	<b>2</b>	A/T Control Component Location .....	13
<b>LUBRICANTS</b> .....	<b>3</b>	A/T Control Component Inspection .....	14
<b>SPECIAL TOOLS</b> .....	<b>3</b>	Converter Stall Test .....	15
<b>TROUBLESHOOTING</b> .....	<b>4</b>	Hydraulic Pressure Test .....	16
<b>SERVICE ADJUSTMENT PROCEDURES</b> .....	<b>10</b>	Governor Pressure Test .....	16
Automatic Transmission Fluid Inspection .....	10	Hydraulic Circuit .....	18
Automatic Transmission Fluid Change .....	11	<b>TRANSMISSION CONTROL</b> .....	<b>30</b>
Throttle Cable Check and Adjustment .....	11	<b>TRANSMISSION ASSEMBLY</b> .....	<b>34</b>
Inhibitor Switch Continuity Inspection .....	12	<b>TRANSMISSION OIL COOLER</b> .....	<b>38</b>

---

**GENERAL INFORMATION**

120002618

Items		Vehicles with 4G63 engine	Vehicles with 4G64 engine
Transmission model		R4AW2-5	R4AW2-5
Type		4-speed full automatic	4-speed full automatic
Gear ratio	1st	2.826	2.826
	2nd	1.493	1.493
	3rd	1.000	1.000
	4th	0.730	0.730
	Reverse	2.703	2.703
Speedometer gear ratio (driven/drive)		22/6	21/6

**SERVICE SPECIFICATIONS**

120002619

Items		Standard value	
Distance between inner cable stopper and end of dust cover mm		0–1	
Lock-up solenoid valve coil resistance (at 20°) Ω		Approx. 13	
Stall speed r/min.	4G63	2,100–2,400	
	4G64	2,300–2,600	
Governor pressure kPa	1,000 r/min.	137–166	
	2,000 r/min.	245–284	
	3,200 r/min.	402–460	
Line pressure kPa	Idle speed	D range	509–588
		R range	774–892
	Stall speed	D range	1,078–1,274
		R range	1,569–1,961
Operation temperature of engine coolant temperature switch °C	On (continuity)		50±3
	Off (no continuity)		43
Clearance between shift lever guide and steering column mm		2.4–3.6	




**LUBRICANTS**

120002620

Items	Specified lubricants	Quantity ℓ
Transmission fluid	DIA QUEEN ATF-SP or equivalent	Approx. 6.8
O-ring for oil filler pipe	DIA QUEEN ATF-SP or equivalent	As required

**SPECIAL TOOLS**

120002621

Tool	Number	Name	Use
	MD998330 (including MD998331)	Oil pressure gauge (2,942 kPa)	Measurement of oil pressure
	MD998920	Adapter	Connection of oil pressure gauge
	MD999563 (including MD998331)	Oil pressure gauge (980 kPa)	Measurement of oil pressure


## TROUBLESHOOTING

120002622

Automatic transmission malfunctions may be caused by the following conditions.

- (1) Improper maintenance and adjustment
- (2) Mechanical malfunctions
- (3) Hydraulic malfunctions
- (4) Poor engine performance

Troubleshooting in the event of any such malfunctions should begin by checking fluid level, ATF condition, manual linkage adjustment, throttle control cable adjustment and other conditions whose deviation from standards can be readily known. Then, road test shall be performed to determine whether or not the problem has been corrected or more diagnosis is necessary. If the problem still persists after these tests and corrections, hydraulic tests should be performed for further troubleshooting.



## ROAD TEST


120000552

Prior to performing road test, be sure to make basic checks including check and adjustment of fluid level and condition and adjustment of the throttle cable. For road test, the transfer must be placed in the 2H (2WD-high) position. In road test, various changes such as slips in transmission and shifting conditions are checked and the transmission operation at each shift position must be checked.


**D RANGE TEST**

12000553


Start with throttle valve opened (50+DIV+ and full), and check upshift from 1-speed → 2-speed, 2-speed → 3-speed and 3-speed → 4-speed. Check that speed change points match shift pattern.




Kickdown traveling at 2-speed, 3-speed and 4-speed. Check that possible kickdown vehicle speed limit at 2-speed → 1-speed, 3-speed → 1-speed, 3-speed → 2-speed, or 4-speed → 1-speed, 4-speed → 3-speed conforms with the shift pattern.




When traveling in 3-speed or 4-speed, release accelerator and shift to L. Check that 3-speed → 2-speed or 4-speed → 3-speed takes place immediately and 2-speed → 1-speed downshift conforms with shift pattern.




When traveling in 3-speed or 4-speed, shift to 2 and L and check engine brake function in each range.





## NOTE

Abnormal noises and vibrations are often caused by an unbalanced propeller shaft, differential, tyre, torque converter, engine, etc. Extremely thorough inspection is therefore required.





## NOTE

- (1) Determine the moment when lock up turns ON by decreased engine r/min. or by a slight shock back and forth.
- (2) Determine the moment when lock up turns OFF by increased engine r/min.
- (3) Check lock up condition by pumping the accelerator slightly. If engine r/min. rises in accordance with throttle valve opening size, determine that the lock up is OFF, if not, determine it ON. (When lock up is OFF, drive power is transferred through the fluid in the torque converter and therefore, when the accelerator pedal is depressed, slipping occurs inside the torque converter with a resulting large increase in engine r/min.)


**2 RANGE TEST**

120000554




**L RANGE TEST**

120000555




R RANGE TEST

12000556



P RANGE TEST

12000557





SHIFT PATTERN

120002623

<4G63 engine>

Throttle opening (%)




TRA0911



**<4G64 engine>**

120002624

Throttle opening (%)



TRA0912

## SERVICE ADJUSTMENT PROCEDURES

120002625

## AUTOMATIC TRANSMISSION FLUID INSPECTION

- (1) Place the vehicle on a level surface.
- (2) Before removing the dipstick, wipe all dirt from area around the dipstick.
- (3) With the selector lever in the "P" position and the parking brake applied, start the engine.
- (4) The engine should be running at idle and the transmission should be warmed up sufficiently. (fluid temperature 70–80°C)
- (5) Move the selector lever through all positions to fill the torque converter and hydraulic circuit with fluid. Then place the lever in the "N" position.
- (6) Check that fluid is at "HOT" level on the oil level gauge. If fluid level is low, add fluid to "HOT" level.

**Transmission fluid: DIA QUEEN ATF-SP or equivalent**

## NOTE


Low fluid level can allow the oil pump to take in air together with fluid, leading to various troubles. Air trapped in hydraulic circuit forms bubbles which make the fluid spongy. This lowers pressure and shows down pressure buildup. If the transmission has too much fluid, gears churn up foam and cause same conditions as when the fluid level is low, resulting in premature deterioration of ATF. In either case, air bubbles can cause overheating and fluid oxidation and varnishing, which can interfere with normal valve, clutch and servo operation. Foaming can also result in fluid escaping from the transmission vent where it may be mistaken for a fluid leak.


- (7) Check fluid condition.

## NOTE

When fluid smells burned, metal bushing or friction material particles are contaminated and a complete overhaul of the transmission is needed. Be sure to examine fluid on the dipstick closely.

- (8) After fluid has been checked, insert the dipstick until it is seated fully to seal out water and dirt.





**AUTOMATIC TRANSMISSION FLUID CHANGE**

120002626

**Caution**

**If ATF change is required due to damage to the transmission, be sure to clean the cooler system.**

- (1) Raise the vehicle on hoist. Place a drain container with large opening under the drain plug (located in bottom of the oil pan).
- (2) Remove the drain plug to let ATF drain.
- (3) Install the drain plug and new gasket and tighten to 20 Nm.
- (4) Refill ATF through the oil level gauge hole until ATF reaches at COLD lower limit of the level gauge.
- (5) Start the engine and allow it to run idle for at least two minutes. Then, with the parking brake and service brake applied, move the selector lever through all positions and finally place in the “N” or “P” position.
- (6) After the transmission is warmed up to the normal operating temperature, recheck the fluid level, which must be between the HOT upper limit and HOT lower limit marks.
- (7) Insert the dipstick fully to prevent dirt from entering the transmission.


**THROTTLE CABLE CHECK AND ADJUSTMENT**

120002627

- (1) Check the throttle lever and the bracket for deformation.
- (2) Measure the distance between the inner cable stopper and the end of the dust cover when the throttle lever is fully opened.

**Standard value: 0–1 mm**



- (3) If the distance is not within the standard value, turn the adjusting nut.



## INHIBITOR SWITCH CONTINUITY INSPECTION

120002628

Position	Terminal No.									
	1	2	3	4	5	6	7	8	9	10
P	○				○	○				○
R	○								○	
N	○				○	○	○			
D	○							○		
2	○	○								
L	○	○								



## INHIBITOR SWITCH AND CONTROL CABLE ADJUSTMENT



120000578

- (1) Shift the manual control lever to the N position.
- (2) Loosen the inhibitor switch mounting bolt.
- (3) Turn the inhibitor switch to align the N position reference line on the inhibitor switch with the groove.
- (4) Tighten the mounting bolt to the specified torque.






**AT CONTROL COMPONENT LOCATION**

120002629

Name	Symbol	Name	Symbol
Overdrive switch	D	Inhibitor switch	B
Overdrive solenoid valve	C	Engine coolant temperature switch	A
Overdrive relay	E	–	–



TRA0815



**A/T CONTROL COMPONENT INSPECTION**

120002630

**INHIBITOR SWITCH**

Refer to P.23-12.

**THROTTLE POSITION SENSOR**

120000582

Refer to GROUP 13 – Service Adjustment Procedures.

**OVERDRIVE SOLENOID VALVE**

120000583

- (1) Disconnect the overdrive solenoid valve connector.
- (2) Measure the resistance between terminal (2) of the overdrive solenoid valve connector and the body earth.

**Standard value: Approx. 13Ω**

- (3) If the resistance is not within the standard value, replace the overdrive solenoid valve.

**OVERDRIVE RELAY CONTINUITY**

120002631




- (1) Remove the overdrive relay.
- (2) Check the continuity between the terminals of the overdrive relay.


Item	Terminal No.	
	2	4
Overdrive relay	○ —	— ○

- (3) Use jumper wires to connect terminal (2) of the overdrive relay to the battery (+) terminal and terminal (4) to the battery (-) terminal.
- (4) Connect and disconnect the jumper wire from the battery (-) terminal. Check the continuity between the terminals of the overdrive relay at this time.

Item	Terminal No.	
	1	3
When connected	○ —	— ○
When disconnected		

- (5) Replace the overdrive relay if necessary.





**ENGINE COOLANT TEMPERATURE SWITCH CONTINUITY**

120002632

- (1) Disconnect the engine coolant temperature switch connector.
- (2) Check the continuity between the switch connector terminal and the switch body.

**Standard value**

Item	Temperature
On (continuity)	50±3°C
Off (no continuity)	43°C

- (3) Replace the engine coolant temperature switch if necessary.

**CONVERTER STALL TEST**

120002633

In this test, the engine maximum speed when the torque converter stalls with the shift lever in the "D" or "R" range is measured to check operation of the torque converter, starter and one-way clutch and check holding performance of the transmission clutch (including brake).

**Caution**

**Do not stand in front or at rear of the vehicle during this test.**

- (1) Check the transmission fluid level. The fluid temperature should be at the level after normal operation (70–80°C). The engine coolant temperature should also be at the level after normal operation (80–90°C).
- (2) Apply chocks to the rear wheels (right and left).
- (3) Mount an engine tachometer.

- (4) Apply the parking and service brakes fully.
- (5) Start the engine.
- (6) With the selector lever in the "D" range, fully depress the accelerator pedal and read off the engine maximum speed.

**Standard value: 2,100–2,400 r/min. <4G63>  
2,300–2,600 r/min. <4G64>**

**NOTE**

When doing so, do not keep the engine running with throttle full open for more than necessary duration (5 seconds or more). If two or more stall tests are needed, place the selector lever in the "N" position and run the engine at about 1,000 r/min. to allow the transmission fluid to cool before another stall test.

- (7) Place the selector lever in the "R" range and perform the test as above.

## JUDGEMENT OF STALL TEST RESULTS

Stall speed in "D" and "R" range is equal to each other but lower than the nominal value.	<ol style="list-style-type: none"> <li>(1) Engine output is low.</li> <li>(2) Starter one-way clutch is faulty. (Faulty torque converter is suspected if it is lower than nominal by more than 600 r/min.)</li> </ol>
Stall speed in "D" range is higher than nominal.	<ol style="list-style-type: none"> <li>(1) O.D. clutch slipping</li> <li>(2) O.D. one-way clutch faulty</li> <li>(3) Forward clutch slipping</li> <li>(4) One-way clutch No. 2 faulty</li> <li>(5) Low line pressure</li> </ol>
Stall speed in "R" range is higher than nominal.	<ol style="list-style-type: none"> <li>(1) O.D. clutch slipping</li> <li>(2) O.D. one-way clutch faulty</li> <li>(3) Direct clutch slipping</li> <li>(4) Brake No. 3 slipping</li> <li>(5) Low line pressure</li> </ol>

## HYDRAULIC PRESSURE TEST

120000596

The hydraulic pressure tests (governor pressure and line pressure tests) are important in determining the causes of transmission failures. Before conducting these tests, fluid level and condition and throttle cable adjustment, etc. must be checked for defects or abnormalities. When conducting the tests, the engine and transmission should be at correct operating temperatures. (engine coolant 80–90°C, transmission fluid 70–80°C.)


## GOVERNOR PRESSURE TEST

120002634

- (1) Place vehicle on a chassis dynamometer.
- (2) Remove plug from governor pressure take off port.
- (3) Install the special tools as shown in figure and place the meter inside vehicle.
- (4) Apply parking brake.
- (5) Start engine.
- (6) Release parking brakes.
- (7) Shift to D and measure governor pressure at each output shaft r/min.

### Standard value:


Output shaft speed (r/min.)	Governor pressure kPa
1,000	137–166
2,000	245–284
3,200	402–460



## JUDGEMENT BY GOVERNOR PRESSURE

Governor pressure is not within the standard value	<ul style="list-style-type: none"> <li>● Line pressure malfunction</li> <li>● Oil leak in governor circuit</li> <li>● Governor malfunction</li> </ul>
--	---





**LINE PRESSURE TEST**

120002635

- (1) Place the vehicle on a chassis dynamometer.
- (2) Remove the plug from the line pressure take off port.
- (3) Install special tool as shown in the figure and place the meter inside vehicle.
- (4) Apply the parking brake.
- (5) Start the engine.
- (6) Place the selector lever in the "D" range.
- (7) Depress the brake pedal firmly by the left foot and operate the accelerator pedal by the right foot to measure the line pressure at each engine rpm. If the measured pressure is not nominal, check adjustment of the throttle cable and readjust if necessary before conducting the test again.
- (8) Place the selector lever in the "R" range and test as above. When measuring the hydraulic pressure for reverse, change the oil-pressure gauge to 3,000 kPa.


**Standard value:**

Items	Line pressure kPa	
	"D" range	"R" range
At idle	509–588	774–892
At stall	1,078–1,274	1,569–1,961

**JUDGEMENT BY LINE PRESSURE**

Hydraulic pressure higher than nominal in all ranges	<ol style="list-style-type: none"> <li>(1) Regulator valve faulty</li> <li>(2) Throttle valve faulty</li> <li>(3) Throttle control cable incorrectly adjusted</li> </ol>
Hydraulic pressure lower than nominal in all ranges	<ol style="list-style-type: none"> <li>(1) Oil pump faulty</li> <li>(2) Regulator valve faulty</li> <li>(3) Throttle valve faulty</li> <li>(4) Throttle control cable incorrectly adjusted</li> <li>(5) O.D. clutch faulty</li> </ol>
Hydraulic pressure lower than nominal in "D" range	<ol style="list-style-type: none"> <li>(1) Large fluid leaks in "D" range hydraulic circuit</li> <li>(2) Forward clutch faulty</li> <li>(3) O.D. clutch faulty</li> </ol>
Hydraulic pressure lower than nominal in "R" range	<ol style="list-style-type: none"> <li>(1) Large fluid leaks in "R" range hydraulic circuit</li> <li>(2) Brake No. 3 faulty</li> <li>(3) Direct clutch faulty</li> <li>(4) O.D. clutch faulty</li> </ol>


HYDRAULIC CIRCUIT  
N (NEUTRAL)



TRA0215

- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>1. Lock-up clutch</li> <li>2. Torque converter</li> <li>3. Overdrive clutch</li> <li>4. Overdrive brake</li> <li>5. Forward clutch</li> <li>6. Direct clutch</li> <li>7. Brake No. 1</li> <li>8. Brake No. 2</li> <li>9. Brake No. 3</li> <li>10. Governor</li> <li>11. Lock-up signal valve</li> <li>12. Accumulator B2</li> <li>13. Accumulator C2</li> <li>14. Accumulator C3</li> <li>15. Lock-up relay valve</li> <li>16. Secondary regulator valve</li> <li>17. Cut-back valve</li> <li>18. Relief valve</li> <li>19. Throttle valve</li> <li>20. Check valve</li> </ul> | <ul style="list-style-type: none"> <li>21. Oil cooler</li> <li>22. Damping check valve</li> <li>23. Oil pump</li> <li>24. Strainer</li> <li>25. Cooler bypass valve</li> <li>26. Primary regulator valve</li> <li>27. 1-2 shift valve</li> <li>28. Low-coast shift valve</li> <li>29. Manual valve</li> <li>30. Low coast modulator valve</li> <li>31. Intermediate shift valve</li> <li>32. Reverse clutch sequence valve</li> <li>33. Intermediate modulator valve</li> <li>34. Detent regulator valve</li> <li>35. 2-3 shift valve</li> <li>36. Overdrive solenoid valve</li> <li>37. Overdrive switch</li> <li>38. D-2 down timing valve</li> <li>39. 3rd-coast shift valve</li> <li>40. 3-4 shift valve</li> </ul> |
|---|---|

P (PARKING)




TRA0216

- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Lock-up clutch             | 21. Oil cooler                    |
| 2. Torque converter           | 22. Damping check valve           |
| 3. Overdrive clutch           | 23. Oil pump                      |
| 4. Overdrive brake            | 24. Strainer                      |
| 5. Forward clutch             | 25. Cooler bypass valve           |
| 6. Direct clutch              | 26. Primary regulator valve       |
| 7. Brake No. 1                | 27. 1-2 shift valve               |
| 8. Brake No. 2                | 28. Low-coast shift valve         |
| 9. Brake No. 3                | 29. Manual valve                  |
| 10. Governor                  | 30. Low coast modulator valve     |
| 11. Lock-up signal valve      | 31. Intermediate shift valve      |
| 12. Accumulator B2            | 32. Reverse clutch sequence valve |
| 13. Accumulator C2            | 33. Intermediate modulator valve  |
| 14. Accumulator C3            | 34. Detent regulator valve        |
| 15. Lock-up relay valve       | 35. 2-3 shift valve               |
| 16. Secondary regulator valve | 36. Overdrive solenoid valve      |
| 17. Cut-back valve            | 37. Overdrive switch              |
| 18. Relief valve              | 38. D-2 down timing valve         |
| 19. Throttle valve            | 39. 3rd-coast shift valve         |
| 20. Check valve               | 40. 3-4 shift valve               |

# 23-20 AUTOMATIC TRANSMISSION – Service Adjustment Procedures


## D-1 (DRIVE 1ST)



TRA0217

- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Lock-up clutch</li> <li>2. Torque converter</li> <li>3. Overdrive clutch</li> <li>4. Overdrive brake</li> <li>5. Forward clutch</li> <li>6. Direct clutch</li> <li>7. Brake No. 1</li> <li>8. Brake No. 2</li> <li>9. Brake No. 3</li> <li>10. Governor</li> <li>11. Lock-up signal valve</li> <li>12. Accumulator B2</li> <li>13. Accumulator C2</li> <li>14. Accumulator C3</li> <li>15. Lock-up relay valve</li> <li>16. Secondary regulator valve</li> <li>17. Cut-back valve</li> <li>18. Relief valve</li> <li>19. Throttle valve</li> <li>20. Check valve</li> </ol> | <ol style="list-style-type: none"> <li>21. Oil cooler</li> <li>22. Damping check valve</li> <li>23. Oil pump</li> <li>24. Strainer</li> <li>25. Cooler bypass valve</li> <li>26. Primary regulator valve</li> <li>27. 1-2 shift valve</li> <li>28. Low-coast shift valve</li> <li>29. Manual valve</li> <li>30. Low coast modulator valve</li> <li>31. Intermediate shift valve</li> <li>32. Reverse clutch sequence valve</li> <li>33. Intermediate modulator valve</li> <li>34. Detent regulator valve</li> <li>35. 2-3 shift valve</li> <li>36. Overdrive solenoid valve</li> <li>37. Overdrive switch</li> <li>38. D-2 down timing valve</li> <li>39. 3rd-coast shift valve</li> <li>40. 3-4 shift valve</li> </ol> |
|---|---|

D-2 (DRIVE 2ND)




TRA0218

- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Lock-up clutch             | 21. Oil cooler                    |
| 2. Torque converter           | 22. Damping check valve           |
| 3. Overdrive clutch           | 23. Oil pump                      |
| 4. Overdrive brake            | 24. Strainer                      |
| 5. Forward clutch             | 25. Cooler bypass valve           |
| 6. Direct clutch              | 26. Primary regulator valve       |
| 7. Brake No. 1                | 27. 1-2 shift valve               |
| 8. Brake No. 2                | 28. Low-coast shift valve         |
| 9. Brake No. 3                | 29. Manual valve                  |
| 10. Governor                  | 30. Low coast modulator valve     |
| 11. Lock-up signal valve      | 31. Intermediate shift valve      |
| 12. Accumulator B2            | 32. Reverse clutch sequence valve |
| 13. Accumulator C2            | 33. Intermediate modulator valve  |
| 14. Accumulator C3            | 34. Detent regulator valve        |
| 15. Lock-up relay valve       | 35. 2-3 shift valve               |
| 16. Secondary regulator valve | 36. Overdrive solenoid valve      |
| 17. Cut-back valve            | 37. Overdrive switch              |
| 18. Relief valve              | 38. D-2 down timing valve         |
| 19. Throttle valve            | 39. 3rd-coast shift valve         |
| 20. Check valve               | 40. 3-4 shift valve               |

# 23-22 AUTOMATIC TRANSMISSION – Service Adjustment Procedures

## D-3 (DRIVE 3RD)




TRA0222

- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Lock-up clutch</li> <li>2. Torque converter</li> <li>3. Overdrive clutch</li> <li>4. Overdrive brake</li> <li>5. Forward clutch</li> <li>6. Direct clutch</li> <li>7. Brake No. 1</li> <li>8. Brake No. 2</li> <li>9. Brake No. 3</li> <li>10. Governor</li> <li>11. Lock-up signal valve</li> <li>12. Accumulator B2</li> <li>13. Accumulator C2</li> <li>14. Accumulator C3</li> <li>15. Lock-up relay valve</li> <li>16. Secondary regulator valve</li> <li>17. Cut-back valve</li> <li>18. Relief valve</li> <li>19. Throttle valve</li> <li>20. Check valve</li> </ol> | <ol style="list-style-type: none"> <li>21. Oil cooler</li> <li>22. Damping check valve</li> <li>23. Oil pump</li> <li>24. Strainer</li> <li>25. Cooler bypass valve</li> <li>26. Primary regulator valve</li> <li>27. 1-2 shift valve</li> <li>28. Low-coast shift valve</li> <li>29. Manual valve</li> <li>30. Low coast modulator valve</li> <li>31. Intermediate shift valve</li> <li>32. Reverse clutch sequence valve</li> <li>33. Intermediate modulator valve</li> <li>34. Detent regulator valve</li> <li>35. 2-3 shift valve</li> <li>36. Overdrive solenoid valve</li> <li>37. Overdrive switch</li> <li>38. D-2 down timing valve</li> <li>39. 3rd-coast shift valve</li> <li>40. 3-4 shift valve</li> </ol> |
|---|---|

D-4 (DRIVE 4TH)

LOCK-UP CLUTCH: OFF




TRA0219

- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>1. Lock-up clutch</li> <li>2. Torque converter</li> <li>3. Overdrive clutch</li> <li>4. Overdrive brake</li> <li>5. Forward clutch</li> <li>6. Direct clutch</li> <li>7. Brake No. 1</li> <li>8. Brake No. 2</li> <li>9. Brake No. 3</li> <li>10. Governor</li> <li>11. Lock-up signal valve</li> <li>12. Accumulator B2</li> <li>13. Accumulator C2</li> <li>14. Accumulator C3</li> <li>15. Lock-up relay valve</li> <li>16. Secondary regulator valve</li> <li>17. Cut-back valve</li> <li>18. Relief valve</li> <li>19. Throttle valve</li> <li>20. Check valve</li> </ul> | <ul style="list-style-type: none"> <li>21. Oil cooler</li> <li>22. Damping check valve</li> <li>23. Oil pump</li> <li>24. Strainer</li> <li>25. Cooler bypass valve</li> <li>26. Primary regulator valve</li> <li>27. 1-2 shift valve</li> <li>28. Low-coast shift valve</li> <li>29. Manual valve</li> <li>30. Low coast modulator valve</li> <li>31. Intermediate shift valve</li> <li>32. Reverse clutch sequence valve</li> <li>33. Intermediate modulator valve</li> <li>34. Detent regulator valve</li> <li>35. 2-3 shift valve</li> <li>36. Overdrive solenoid valve</li> <li>37. Overdrive switch</li> <li>38. D-2 down timing valve</li> <li>39. 3rd-coast shift valve</li> <li>40. 3-4 shift valve</li> </ul> |
|---|---|

## 23-24 AUTOMATIC TRANSMISSION – Service Adjustment Procedures

D-4 (DRIVE 4TH)

LOCK-UP CLUTCH: ON




TRA0220

- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Lock-up clutch             | 21. Oil cooler                    |
| 2. Torque converter           | 22. Damping check valve           |
| 3. Overdrive clutch           | 23. Oil pump                      |
| 4. Overdrive brake            | 24. Strainer                      |
| 5. Forward clutch             | 25. Cooler bypass valve           |
| 6. Direct clutch              | 26. Primary regulator valve       |
| 7. Brake No. 1                | 27. 1-2 shift valve               |
| 8. Brake No. 2                | 28. Low-coast shift valve         |
| 9. Brake No. 3                | 29. Manual valve                  |
| 10. Governor                  | 30. Low coast modulator valve     |
| 11. Lock-up signal valve      | 31. Intermediate shift valve      |
| 12. Accumulator B2            | 32. Reverse clutch sequence valve |
| 13. Accumulator C2            | 33. Intermediate modulator valve  |
| 14. Accumulator C3            | 34. Detent regulator valve        |
| 15. Lock-up relay valve       | 35. 2-3 shift valve               |
| 16. Secondary regulator valve | 36. Overdrive solenoid valve      |
| 17. Cut-back valve            | 37. Overdrive switch              |
| 18. Relief valve              | 38. D-2 down timing valve         |
| 19. Throttle valve            | 39. 3rd-coast shift valve         |
| 20. Check valve               | 40. 3-4 shift valve               |



D-K/D (DRIVE KICK DOWN)

4TH → 3RD




TRA0221

- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>1. Lock-up clutch</li> <li>2. Torque converter</li> <li>3. Overdrive clutch</li> <li>4. Overdrive brake</li> <li>5. Forward clutch</li> <li>6. Direct clutch</li> <li>7. Brake No. 1</li> <li>8. Brake No. 2</li> <li>9. Brake No. 3</li> <li>10. Governor</li> <li>11. Lock-up signal valve</li> <li>12. Accumulator B2</li> <li>13. Accumulator C2</li> <li>14. Accumulator C3</li> <li>15. Lock-up relay valve</li> <li>16. Secondary regulator valve</li> <li>17. Cut-back valve</li> <li>18. Relief valve</li> <li>19. Throttle valve</li> <li>20. Check valve</li> </ul> | <ul style="list-style-type: none"> <li>21. Oil cooler</li> <li>22. Damping check valve</li> <li>23. Oil pump</li> <li>24. Strainer</li> <li>25. Cooler bypass valve</li> <li>26. Primary regulator valve</li> <li>27. 1-2 shift valve</li> <li>28. Low-coast shift valve</li> <li>29. Manual valve</li> <li>30. Low coast modulator valve</li> <li>31. Intermediate shift valve</li> <li>32. Reverse clutch sequence valve</li> <li>33. Intermediate modulator valve</li> <li>34. Detent regulator valve</li> <li>35. 2-3 shift valve</li> <li>36. Overdrive solenoid valve</li> <li>37. Overdrive switch</li> <li>38. D-2 down timing valve</li> <li>39. 3rd-coast shift valve</li> <li>40. 3-4 shift valve</li> </ul> |
|---|---|

# 23-26 AUTOMATIC TRANSMISSION – Service Adjustment Procedures

D-3 (DRIVE 3RD)


OVERDRIVE SWITCH: OFF



TRA0223

- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>1. Lock-up clutch</li> <li>2. Torque converter</li> <li>3. Overdrive clutch</li> <li>4. Overdrive brake</li> <li>5. Forward clutch</li> <li>6. Direct clutch</li> <li>7. Brake No. 1</li> <li>8. Brake No. 2</li> <li>9. Brake No. 3</li> <li>10. Governor</li> <li>11. Lock-up signal valve</li> <li>12. Accumulator B2</li> <li>13. Accumulator C2</li> <li>14. Accumulator C3</li> <li>15. Lock-up relay valve</li> <li>16. Secondary regulator valve</li> <li>17. Cut-back valve</li> <li>18. Relief valve</li> <li>19. Throttle valve</li> <li>20. Check valve</li> </ul> | <ul style="list-style-type: none"> <li>21. Oil cooler</li> <li>22. Damping check valve</li> <li>23. Oil pump</li> <li>24. Strainer</li> <li>25. Cooler bypass valve</li> <li>26. Primary regulator valve</li> <li>27. 1-2 shift valve</li> <li>28. Low-coast shift valve</li> <li>29. Manual valve</li> <li>30. Low coast modulator valve</li> <li>31. Intermediate shift valve</li> <li>32. Reverse clutch sequence valve</li> <li>33. Intermediate modulator valve</li> <li>34. Detent regulator valve</li> <li>35. 2-3 shift valve</li> <li>36. Overdrive solenoid valve</li> <li>37. Overdrive switch</li> <li>38. D-2 down timing valve</li> <li>39. 3rd-coast shift valve</li> <li>40. 3-4 shift valve</li> </ul> |
|---|---|

**2-2 (SECOND 2ND)**




TRA0224

- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Lock-up clutch             | 21. Oil cooler                    |
| 2. Torque converter           | 22. Damping check valve           |
| 3. Overdrive clutch           | 23. Oil pump                      |
| 4. Overdrive brake            | 24. Strainer                      |
| 5. Forward clutch             | 25. Cooler bypass valve           |
| 6. Direct clutch              | 26. Primary regulator valve       |
| 7. Brake No. 1                | 27. 1-2 shift valve               |
| 8. Brake No. 2                | 28. Low-coast shift valve         |
| 9. Brake No. 3                | 29. Manual valve                  |
| 10. Governor                  | 30. Low coast modulator valve     |
| 11. Lock-up signal valve      | 31. Intermediate shift valve      |
| 12. Accumulator B2            | 32. Reverse clutch sequence valve |
| 13. Accumulator C2            | 33. Intermediate modulator valve  |
| 14. Accumulator C3            | 34. Detent regulator valve        |
| 15. Lock-up relay valve       | 35. 2-3 shift valve               |
| 16. Secondary regulator valve | 36. Overdrive solenoid valve      |
| 17. Cut-back valve            | 37. Overdrive switch              |
| 18. Relief valve              | 38. D-2 down timing valve         |
| 19. Throttle valve            | 39. 3rd-coast shift valve         |
| 20. Check valve               | 40. 3-4 shift valve               |

# 23-28 AUTOMATIC TRANSMISSION – Service Adjustment Procedures


## L (LOCK UP)



TRA0225

- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Lock-up clutch             | 21. Oil cooler                    |
| 2. Torque converter           | 22. Damping check valve           |
| 3. Overdrive clutch           | 23. Oil pump                      |
| 4. Overdrive brake            | 24. Strainer                      |
| 5. Forward clutch             | 25. Cooler bypass valve           |
| 6. Direct clutch              | 26. Primary regulator valve       |
| 7. Brake No. 1                | 27. 1-2 shift valve               |
| 8. Brake No. 2                | 28. Low-coast shift valve         |
| 9. Brake No. 3                | 29. Manual valve                  |
| 10. Governor                  | 30. Low coast modulator valve     |
| 11. Lock-up signal valve      | 31. Intermediate shift valve      |
| 12. Accumulator B2            | 32. Reverse clutch sequence valve |
| 13. Accumulator C2            | 33. Intermediate modulator valve  |
| 14. Accumulator C3            | 34. Detent regulator valve        |
| 15. Lock-up relay valve       | 35. 2-3 shift valve               |
| 16. Secondary regulator valve | 36. Overdrive solenoid valve      |
| 17. Cut-back valve            | 37. Overdrive switch              |
| 18. Relief valve              | 38. D-2 down timing valve         |
| 19. Throttle valve            | 39. 3rd-coast shift valve         |
| 20. Check valve               | 40. 3-4 shift valve               |

R (REVERSE)



TRAQ226


- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Lock-up clutch             | 21. Oil cooler                    |
| 2. Torque converter           | 22. Damping check valve           |
| 3. Overdrive clutch           | 23. Oil pump                      |
| 4. Overdrive brake            | 24. Strainer                      |
| 5. Forward clutch             | 25. Cooler bypass valve           |
| 6. Direct clutch              | 26. Primary regulator valve       |
| 7. Brake No. 1                | 27. 1-2 shift valve               |
| 8. Brake No. 2                | 28. Low-coast shift valve         |
| 9. Brake No. 3                | 29. Manual valve                  |
| 10. Governor                  | 30. Low coast modulator valve     |
| 11. Lock-up signal valve      | 31. Intermediate shift valve      |
| 12. Accumulator B2            | 32. Reverse clutch sequence valve |
| 13. Accumulator C2            | 33. Intermediate modulator valve  |
| 14. Accumulator C3            | 34. Detent regulator valve        |
| 15. Lock-up relay valve       | 35. 2-3 shift valve               |
| 16. Secondary regulator valve | 36. Overdrive solenoid valve      |
| 17. Cut-back valve            | 37. Overdrive switch              |
| 18. Relief valve              | 38. D-2 down timing valve         |
| 19. Throttle valve            | 39. 3rd-coast shift valve         |
| 20. Check valve               | 40. 3-4 shift valve               |

## TRANSMISSION CONTROL

## REMOVAL AND INSTALLATION

**Pre-removal and Post-installation Operation**

- (1) Air Cleaner Removal and Installation <Petrol-powered vehicles> (Refer to GROUP 15 – Air Cleaner.)  
 (2) Column Cover Upper, Lower, Under Cover Removal and Installation (Refer to GROUP 37A – Steering Wheel and Shaft.)




A09W0090

**Transmission control cable assembly removal steps**

- B◄
1. Snap pin
  2. Washer
  3. Clevis pin
  4. Transmission control cable connection (selector lever side)
  5. Clip
  6. Snap pin
  7. Washer
  8. Clevis pin

9. Transmission control cable connection (transmission side)
10. Clip
11. Shift control bracket
12. Transmission control cable assembly




A09W0065

**Control rod removal steps**


1. Pin
2. Retainer
3. Boot
4. Selector lever support cover
5. Selector lever assembly
6. Detent plate
7. Snap ring
8. Washer

9. Bushing
10. Shift link lever
11. Bushing
12. Lever
13. Bushing
- ▶A◀ 14. Shift lever guide
15. Spring
16. Bushing
17. Control rod

Lubricant points



A09W0064




**INSPECTION**

**OVERDRIVE SWITCH CONTINUITY INSPECTION**


Switch position	Terminal No.		
	1	2	3
OFF	○	—	○
ON	○	○	—



**INSTALLATION SERVICE POINTS****▶A◀ SHIFT LEVER GUIDE INSTALLATION**

Install so that the distance shown in the illustration is at the standard value.

**Standard value (A): 2.4–3.6 mm**

**▶B◀ TRANSMISSION CONTROL CABLE (SELECTOR LEVER SIDE) INSTALLATION**


- (1) Shift the selector lever to the N position.
- (2) Tighten the fixing bolt while gently pushing the shift link lever in the direction of the arrow in the illustration.

## TRANSMISSION ASSEMBLY

## REMOVAL AND INSTALLATION

**Pre-removal and Post-installation Operation**


- (1) Transmission Fluid Draining and Supplying  
(Refer to P. 23-11.)
- (2) Under Cover Side Panel, Under Cover Panel  
Removal and Installation (Refer to GROUP 42 –  
Under Cover.)
- (3) Propeller Shaft Removal and Installation  
(Refer to GROUP 25 – Propeller Shaft.)
- (4) Front Exhaust Pipe (L.H), (R.H) Removal and  
Installation (Refer to GROUP 15 – Exhaust Pipe and  
Muffler.)
- (5) Battery, Battery Tray Removal and Installation

**Removal steps**

1. Oil cooler tube connection
2. Snap pin
3. Washer
4. Pin
5. Transmission control cable connection
6. Clip
7. Shift control bracket



8. Vehicle speed sensor connector
9. Solenoid valve connector
10. Inhibitor switch connector
11. Throttle cable connection




- ◀A▶ 12. Starter motor
- 13. Bell housing cover
- 14. Fan shroud
- ◀B▶ 15. Torque converter and drive plate connection bolts
- 16. Oil level gauge assembly
- 17. O-ring
  - Support the transmission with a transmission jack.
- 18. Transmission mount crossmember assembly
- 19. Transmission mount insulator assembly
- ▶A◀ 20. Transmission assembly

**REMOVAL SERVICE POINTS****◀A▶ STARTER MOTOR REMOVAL**

Remove the starter motor with the starter motor harnesses still connected, and secure it inside the engine compartment.

**◀B▶ TORQUE CONVERTER AND DRIVE PLATE CONNECTION BOLTS REMOVAL**

- (1) Remove the connection bolts (6 places) while turning the crankshaft.
- (2) Press in the torque converter to the transmission side so the torque converter does not remain on the engine side.

**INSTALLATION SERVICE POINTS****▶A◀ TRANSMISSION ASSEMBLY INSTALLATION**

The sizes of the mounting bolts are different. So be sure not to confuse them.

Bolt	Head mark	d×l mm
A	7T	10×40
B <4D56>		10×55
C <4G63, 4G64>		10×60
D		10×65


**►B◄ THROTTLE CABLE INSTALLATION**

After installing the throttle cable, adjust it by the following procedure.

**<4D56, 4G63>**

- (1) Remove the cable from the boot outer cable side until the inner cable stopper can be seen.
- (2) Open the throttle lever completely and adjust the cable with the adjusting nut so that the distance between the inner cable stopper and the outer cable end is at the standard value.


**Standard value (A): 34–35 mm <4D56>  
54–55 mm <4G63>**



**<4G64>**

Open the throttle lever completely and adjust the cable with the adjusting nut so that the distance between the inner cable stopper and the dust cover end is at the standard value.

**Standard value (A): 0–1 mm**




**TRANSMISSION OIL COOLER**

120002227

**REMOVAL AND INSTALLATION****Pre-removal and Post-installation Operation**

- (1) Transmission Fluid Draining and Supplying  
(Refer to P. 23-11.)
- (2) Front Bumper Removal and Installation  
(Refer to GROUP 51 – Front Bumper.)



A09W0089

**Removal steps**

1. Hose
2. Oil return tube
3. Oil feed tube