

MMC メンテナンスインフォメーション (For detailed procedure please follow maintenance reference notebook.)

MU900229

Please be sure to use Mitsubishi genuine exchange parts and oils and grease, please refer to our catalogue.				
Engine oil Replacement	Petrol, as well as	except turbo car	15,000 km otherwise every 12 months (not less than SE grade)	
	LPG car	turbo car	5,000 km otherwise every 6 months (not less than SE grade)	
	Diesel car		5,000 km otherwise every 6 months (not less than CC grade, turbo car not less than CD grade)	
Engine oil Filter replacement	petrol car (except turbo car) • LPG car		15,000 km otherwise every 12 months	
	petrol car (turbo car) • diesel car		10,000 km otherwise every 12 months	
Timing belt replacement (except 4M40 diesel engine)			every 100,000 km	
Fuel filter Replacement	petrol car (MPI engine)		every 100,000 km	
	petrol car (except MPI engine) • LPG car		every 40,000 km	
	diesel car		every 20,000 km	
Transmission Oil change	manual transmission	FF series 2WD car (except light motor vehicle - 550 cc)	every 80,000 km	DIA Clean Multi gear Oil #75W/85W
		4WD car. FR series 2WD car as well as light motor vehicle - 550 cc	every 40,000 km	
	automatic transmission		every 40,000 km	DIA Clean ATF-SP
Transfer case oil change (4WD car only)		every 40,000 km	DIA Clean Multi gear Oil #75W/85W	
Differential Oil change	Normal Differential		every 80,000 km	DIA Clean Super Hi gear oil #80, #90
	Limited Slip Differential	VCU style	every 40,000 km	
		machine mechanism style		DIA Clean LSD Gear Oil
Air-Conditioning equipped car Please occasionally use air conditioning to oil lubricate compressor seals.		Refrigerant used	HCF-134a (R134a)	Zekusel ZXL 100 PG Nippon Denso ND-OIL 8
		Air Compressor oil used	Mitsubishi SUN PAG 56	