


## DISASSEMBLY AND REASSEMBLY


E54ZDA-

**Disassembly steps**

1. Bulb
2. Altimeter reset knob
3. Meter panel
4. Case
5. Altimeter assembly
6. Inclinator assembly
7. Connector and harness connection
8. Thermometer assembly



16 G 0 5 2 0

**SERVICE POINT OF REMOVAL**

E54ZEAA

**7. DISCONNECTION OF CONNECTOR FROM HARNESS CONNECTION**

- (1) Use a flat-tipped screwdriver or similar tool to remove the connectors from the harnesses.

**NOTE**

- The harness positions should be marked with the harness colours for reference when installing.

